

PARAFIN WAX

Code : G813



- Paraffin wax in engineering testing laboratories is used for embedding and preserving samples, especially in materials like soil, rock, and biological specimens, for microscopic examination. It is also used in certain tests to create molds or as a sealing material to protect samples during storage or transportation.

ORDERING INFORMATION

Item	Code
TRICHLOROETHYLENE	G801X00XH
METHYLENE BLUE POWDER - 100 g	G802X00XH
SULPHUR	G803X00XH
GRAPHITE	G804X00XH
SODIUM SULFATE	G805X00XH

MAGNESIUM SULFATE	G806X00XH
-------------------	-----------

BARIUM CHLORIDE	G807X00XH
-----------------	-----------

CALCIUM CHLORIDE	G808X00XH
------------------	-----------

SODIUM HYDROXIDE	G809X00XH
------------------	-----------

FORMALDEHYDE (Stock Solution)	G810X00XH
-------------------------------	-----------

SODIUM HEXAMETAPHOSPHATE	G811X00XH
--------------------------	-----------

SILICA GEL	G812X00XH
------------	-----------

PARAFIN WAX	G813X00XH
-------------	-----------

KAOLINITE	G814X00XH
-----------	-----------

QUANTAB CHLORIDE TITRATOR 1175 TYPE	G815X00XH
-------------------------------------	-----------

QUANTAB CHLORIDE TITRATOR 1176 TYPE	G816X00XH
-------------------------------------	-----------